# NEO PRODUCTS - WORK INSTRUCTION
BETMAKERS TSST SERVICE

| NUMBER	ISSUE	CHANGE	DATE	ISSUED BY
15201-SERV013	A	Initial Production Release	30-09-22	LD
DESCRIPTION	B	Filename updated (ECN 6477)	13-10-23	LD
TSST SPARE BETSLIP	C			
READ KIT - FREE ISSUE	D			
MSR	E			

ITEMS NEEDED TO PERFORM THIS TASK
HAND TOOLS ONLY

STANLEY KNIFE

| ITEM #	STOCK CODE	DESCRIPTION	QTY
1	15201-FI001	MSR READER	1.00
2	15201-FM065DF	BETSLIP READER MOUNT PLATE	1.00
3	15201-IM002AB	MSR BEAK COVER	1.00
4	MHMIS-000136	LATCH SWELL ACTION SERIES	1.00
5	MHTAP-DS0012	3M VHB D/SIDED 12X2.3MM 33M ROLL	0.10
6	SCSPL-000019	SCREW TAPTITE 6-32x3/8 XR PAN	4.00
7			
8			
9			
10			
11			
12			
13			
14			

STEP	IMAGE	DESCRIPTION
1		Prior to starting the TSST SPARE CUSTOMER SCREEN KIT, switch the plug from I → O on the underside of the Kiosk. Remove the Power Lead & Network Cable.
2		Unlock and open the Top Door by pushing the Button on the RH side of the Top Door. This provides access to the printer paper.
3		Undo the Latch Swell to disengage the green tray.

STEP	IMAGE	DESCRIPTION
4		Remove the MSR Module from the peripheral tray.
5		Tilt the MSR Module to access the Power connector located behind the MSR Module. Unplug the power connector.
6		Remove TSST SPARE BETSLIP READ KIT from packaging. Discard packaging. To re-install the replacement MSR Module, follow Steps 2 to 6 in reverse.

| 7 | | Close the Top Door by pushing down waiting for a "click" to indicate locked position. |
| 8 | | Install the Power Lead & Network Cable to the underside of the Kiosk.

Switch the plug from O → I. |